









BARBARA

GRK GS2 EVO用 分解図

-  M3×8 ボタンビス BHCS ×2
-  M3×10 ボタンビス BHCS ×2
-  M3×12 ボタンビス BHCS ×2
-  M3×15 ボタンビス BHCS ×2
-  M3×6 皿ビス FHCS ×8
-  M3×8 皿ビス FHCS ×14
-  M3×10 皿ビス FHCS ×3
-  M3×15 皿ビス FHCS ×4

